

with & without dwc (Direct Water Connection)

- 1 Ensure machine is off
- 2 Remove and empty water tank(s)
- 3 Wash water tank(s) with mild soap
- 4 Return the water tank(s) to the machine (and fill with fresh water if you don't have a direct water connection)
- 5 Turn the machine on; the machine will do an automatic rinsing
- 6 If you have a direct water connection, repeat step 1 to 5 again
- 7 Run a few drinks without coffee capsules (on each head, if applicable)
- 8 Repeat step 7, if needed

Watch video «start/restart» www.nespresso.com

Note: refer to the machine user manual for complete cleaning guidelines or call the Club if you need any assistance.