

1 - Prior to cleaning and disinfecting the machine, it is recommended to:

- a Wear personal protective equipment (PPE) such as a face mask and disposable gloves.
- b Use disinfectant solution or disinfectant wipes.
- c Turn the machine off during disinfection.

2 - To clean and disinfect:

- a Remove and wash all external components, such as, the water tank, drip tray, cup holder support and capsule container.
- b Perform a general cleaning of the exterior surface with a soft nontoxic cleaner and a disposable paper towel.
- c Use warm water on areas that come into contact with water or milk (e.g. coffee and milk outlets or milk sensor suction hoses).
- d Gently wipe disinfectant on common touch areas of the machine, such as, levers, handles and push buttons only.
- e Allow 2-3 minutes for the disinfectant to dry. Do not wipe it off.

3 - To turn the machine on:

- a Refer to "Machine Start-Up Process after Long Standstill"
 If you are operating the machine after an extended period of time.
 or
- b Proceed as normal if the machine has been in regular use the last few months.

Note: refer to the machine user manual for complete cleaning guidelines or call the Club if you need any assistance.